



Place hose in the filter housing and fill the hot tub with water. Fill to above all the jets, this will allow water to flow freely into the filter compartment.

## 1 Install Silver Cartridge


Install your silver cartridge. Silver has long been known for its sanitizing, antimicrobial properties. The cartridge works by automatically dissolving trace amounts of mineral elements into the water. Those elements act as a sanitizer to destroy bacteria and viruses to give you clean, clear water with minimal chlorine added.

3 Turn On

Plug in or turn on breaker to power the hot tub. Turn jets on to purge air from the system, once purged, turn the jets off.

Check

Verify there are no flow related errors and the circulation pump system has initialized properly. Now adjust set temperature.



Add a "shock" dose of chlorine. Typically 1.5 or 2 times the normal dose. Test the water and add pH adjustment if necessary.

## NOTE:

120v hot tub will get hot in ~20-36 hours. 240v hot tub will get hot in ~6-9 hours.

